


Navigation


Location

You can record and store the locations in the device.

Enter **NAVIGATION-History Routes** to open the activity list, select the wanted routes, device will show its GPS track, choose **Navigation** or **Return**, select middle button to enter the data display pages, select middle button to zoom in or zoom out.



Note: the activities under **MEMORY** menu can be also opened by navigation:
MEMORY-Saved Activity-Last Activity/All Activities/Historical-Map



Road map

iGS618 support road map in fit, gpx and tcx formats.

After confirm the plan routes, copy the road map file into iGPSPORT \ Navigation Folder by USB cable, power on iGS618, you can find the road map under **Navigation-User Routes**, open the file to start **Navigation** or **Return**.

Note: the length of the file name should be within 28 characters, or device cannot recognize it.

Navi Setting

Customize Data-On /Off

It will show 1-2 data items if choose on

Set Page

Set data items, same setting as the **Set page** under the **Race Mode** menu.

North-upward on/off

North-upward On: navigation displayed based on North-upward


North-upward Off: navigation displayed based on Head-upward.

Turning indicator

When **Turning indicator** On, device will indicate the turning direction and distance with arrow and sound when then turning point is within 1 kilometer.


Route Elevation

When **Route Elevation** On, you can view an elevation plot of the routes(based on there was valid height data exist in the route files)



Custom Data Off

Route Elevation On



Custom Data On

